


# NDT REPORTS

## 12.0 NDT REPORTS

The **NDT REPORTS** tab allows you to check and update the NDT request raised in the web application, by adding and updating your inspection details. This feature automatically updates and synchronizes your inspection details with the NDT report that is uploaded in the web application.

image.1651724728567.png

There are four main types of NDT Reports: **RT**, **UT**, **DPT**, and **MPT**.


image.1651724746255.png **Note:** when you click the **NDT REPORTS** tab in the dashboard, the **NDT Reports** page displays a list of reports corresponding to today and previous day. However, if you want to view the reports for other dates, you must navigate to the **TAKE OFFLINE DATA** option. (See "[TAKE OFFLINE DATA](#)" for more details.)

1. Tap **NDT REPORTS**. See Fig 2.3.

The **NDT Reports** page opens with a list of reports for the corresponding types such as **RT**, **UT**, **DPT**, and **MPT**. You must select the respective type to view the relevant reports.

image.1651724769042.png

**Figure 13.1 NDT Reports page**

image.1651724786754.png **Tip:** I. You can configure displaying of the number of reports per page by selecting **10**, **25**, **50** or **100**, accordingly.

1. If you want to filter one report among the list of reports, you must enter the report number, NDT request number or inspection date details in the respective boxes given in the **NDT Reports** page.

The **NDT Reports** page contains multiple fields such as **Report Number**, **NDT Request number**, **Inspection Date**, **Result**, **Signature**, **Attach**, and **Sync**. (See the topic "[The MIR page contains the following fields](#)" for more details about each field in the **NDT Reports** page.)

image.1651724796738.png available.

**Tip:** In the **NDT Reports** option, the **Print** field is not available.

## To add your inspection result for NDT RT report

1. Tap **RT**.
2. Once you find out the NDT RT report where you need to add your inspection details, tap [image-1651724814358.png](#)

Image not found or type unknown  
(**Result** icon) to add your inspection results, See Fig 13.1.

The **Result** page opens with a list of reports with the material details.

[image-1651724834755.png](#)

Image not found or type unknown

Each report shows material specifications such as drawing number, spool number, joint number, and joint length.

3. In the **Remarks** box, type your remarks if any.

[image-1651724869487.png](#)

4. If you want to add the new NDT RT report, tap [Image not found or type unknown](#) (**Add icon**). A new window opens.

[image-1651724886359.png](#)

Image not found or type unknown

- In the **Marker** box, enter the marker number.
- In the **Result** box, tap and choose **NA, Accepted, Rejected or Reshoot** from a drop-down list based on your inspection details.
- In the **Remarks** box, type your remarks if any.
- Tap **Save**.

[image-1651725036927.png](#)

5. If you want to edit the existing NDT RT report, tap [Image not found or type unknown](#) (**Edit icon**). A new window opens.

[image-1651725070898.png](#)

Image not found or type unknown

- In the **Marker** box, check and edit the marker number if you want.
- In the **Result** box, tap and choose **NA, Accepted, Rejected or Reshoot** from a drop-down list based on your inspection details.
- In the **Remarks** box, type your remarks if any.
- Tap **Save**.

6. If you want to delete any existing NDT RT report from a list, tap  (Delete icon).

 image-1651726418901.png

Image not found or type unknown

You will receive the following notification: “**Confirm delete?**”. If you want to delete tap **Yes**, otherwise tap **No**.

7. Tap **Save**.

### To add your signature for NDT RT Report

Once you have saved your inspection results, the **Result** page automatically redirects you into the **Signature** page. Otherwise, tap

 image-1651726431481.png

Image not found or type unknown (Signature icon), See Fig 10.1.


To know how to add your signature, see the topic “[To add your signature](#)”.

### To add your inspection result for NDT UT, DPT, and MPT reports

 image-1651726442060.png

Image not found or type unknown **Note:** Follow the same procedure to add result for the NDT UT, DPT or MPT reports.

1. Tap **UT,DPT** or **MPT**, See Fig 13.1.
2. Once you find out the NDT UT, DPT or MPT report, where you need to add your inspection

 image-165172645537.png

details, tap  (Result icon) to add your inspection results, See Fig 13.1.

The **Result** page opens with a list of reports with the material details.

 image-1651726478774.png

Image not found or type unknown

Each report shows material specifications such as drawing number, spool number, joint number, and joint length.

3. In the **Remarks** box, type your remarks if any.

4. In the **Result** box, tap and choose **Accepted, Rejected or Cancelled** from a drop-down list based on your inspection details.
5. In the **Remarks** box, type your remarks if any.
6. Tap **Save**.

### To add your signature for NDT UT, DPT, and MPT reports

Once you have saved your inspection results, the **Result** page automatically redirects you into the **Signature** page. Otherwise, tap

[image-1651726493947.png](#)

Image not found (Signature icon), See Fig 10.1.

To know how to add your signature, see the topic "[To add your signature](#)".

---

Revision #4

Created 5 May 2022 04:24:06

Updated 10 December 2024 05:46:10 by Shybin