

# User Management

## 1.1 Downloading *cuteQM* app

To use the *cuteQM* app you must first download it from the **Play Store**.

1. Open the **Play Store** and search for "*cuteQM*".
2. Download and install the *cuteQM* app on your mobile phone.
3. After installation, open the *cuteQM*

You are ready to go!


## 1.2 Log in

After installation, when you open the *cuteQM* app you may be asked to Login. Follow the steps to successfully log into your account.







1. Before enter your user id and password, tap  (Settings icon) and enter the app URL that is provided by your administrator.

2. Tap **Save**.

3. Enter your user id and password in the allocated fields.

4. Tap **Log in** to complete the process.

The home screen of the *cuteQM* app is appeared.

## 1.3 Home screen of *cuteQM* app





**Figure 2.2 Home screen of *cuteQM* app**

image-1651671928722.png

Image not found or type unknown (show/hide icon) helps to show/hide the user id information that is displayed in the left pane of the home screen. if you touch this icon the information appears on, if you touch this icon again the information goes off.

image-1651671928722.png

Image not found or type unknown provided with a down arrow. If you click the down arrow, a list opens with three options such as **Clear Storage**, **Sync Data**, and **Log out**.

- **Clear Storage** - clears all data in this app. Tap the **Clear Storage** option to delete all the data.
- **Sync Data**- synchronizes your inspection results with the respective reports in the web application. If your inspection results are not automatically synchronized with the web application, tap the **Sync Data** option for manual synchronization.
- **Log out** - See "[Log out](#)" section for details about log out of the app.

image-1651671946674.png

Image not found or type unknown **Project** helps to select the project. To select the project,

1. Tap the **Project** box, and select the project from a drop-down list.

image-1651671956919.png

Image not found or type unknown **Module** helps to select the module. To select the module,

2. Select **Piping** under the **Module**
3. Tap **GO**.

A dashboard of the app is appeared.

image-1651671969459.png

Image not found or type unknown Note: The dashboard does not display **MILL CERTIFICATES** and **TEST EQUIPMENT** tabs unless your administrator adds your role in the **cuteQM\_Certificate Access** option in the web application.

image-1651671995897.png

Image not found or type unknown

**Figure 2.3 Dashboard of cuteQM app**

You can navigate through the app using the dashboard. The dashboard shows different tabs according to the type of project and module that you have selected.

## 1.4 Log out

Log out of your user's account from this **Log out** option. This command ends your current session of the app work.

1. Tap the Log out option for logging out of the app. This will lead you back to the Log in Screen. See Fig 2.2.

---

Revision #9

Created 4 May 2022 06:15:00

Updated 10 December 2024 05:40:36 by Shybin