

Engineering

The **Engineering** team can add the pressure vessel drawings, bill of material, and joints to the system.

1 Drawings

The **Drawings** tab in the **Data** menu used to add the drawings related with the pressure vessel.

1. Click **Drawings**


The **Drawings** page opens.

image-1651064647999.png

Figure 1.1: Drawings page

Add a Drawing

If you want to add a drawing, do the following steps,

1. Click  (ADD button) in the **Drawings** See Fig 1.1.

The page shows a new box to add the details of the drawing.

image-1651064732879.png

2. In the Drawing Number box, enter the drawing number.
3. In the Description box, enter the description for the added drawing.
4. In the Revision box, enter the revision number of the drawing.
5. In the Approved box, if the drawing has approved, select Yes otherwise select No. If there is no need for approval means select NA.
6. In the Sheets box, enter the sheet number.
7. In the Remarks box, enter your remarks if any.
8. Click Save.

The drawing is successfully added.

Edit a Drawing

If you want to edit any existing drawing in the **Drawings** page, do the following,

[image-1651064824216.png](#)

1. Click  in the **Edit** column for the respective drawing. See Fig 7.1.

The page shows the details of added drawing.

[image-1651064843327.png](#)


Image not found or type unknown

2. Click on any box where you want to edit the details, and then edit the details in the respective box.
3. Click **Save**.

Production users will be notified if there are any changes to the drawing.


Delete a Drawing

[image-1651064894](#)

If you want to delete any specific drawing from the list of drawings, you can use  (Delete icon) provided in the **Delete** field of the **Drawings** page.


Attach a File into a Drawing

[image-1651065007115.png](#)

If you want to attach a file with any drawing listed in the **Drawings** page, you can use  (Attach icon) provided in the **Attachment** column for the respective drawing.

Attach a File into a Pressure Vessel Built Drawing

If you want to attach a file with any pressure vessel built drawing listed in the **Drawings** page, you

can use  (Attach icon) provided in the **As Built Drawing** column for the respective drawing.

Export Drawings List

You can export a list of drawings added in the **Drawings** page in the excel formats by using [excelimg.png](#)

Image not found or type unknown (Excel button)

2 Bill of Material

Bill of Material is a comprehensive inventory of the raw materials, assemblies, sub assemblies, parts and components, as well as the quantity of each, needed to the pressure vessel module.

The **Bill of Material** menu used to add the bill of material details.

1. Click **Bill of Material**

The **Bill of Materials** page opens.

[image-1651065130907.png](#)

Image not found or type unknown

Figure 1.2: Bill of Materials page

Add a Bill of Material

If you want to add a bill of material, do the following steps,

[image-1651065190556.png](#)

1. Click [Image not found or type unknown \(ADD button\)](#) in the **Bill of Materials** See Fig 7.2.

The page shows a new box to add the details of the bill of material.

[image-1651065209995.png](#)

Image not found or type unknown

2. In the Drawing Number box, select the drawing number from a drop-down list.
3. In the Part No box, enter the part number.
4. In the Material Description box, enter the description for the bill of material.
5. In the Material Specification box, select the material specification.
6. In the Material Dimension box, enter the material dimension.


7. In the Qty box, enter the quantity of the material.
8. In the Remarks box, enter your remarks if any.
9. If the material is cut from a plate, select the checkbox of the Cutting from Plate? option.
10. In the **Group** box, select the group from a drop-down list.
11. In the **Point of Sale (POS)** box, select the POS from a drop-down list.
12. Click **Save**.

The bill of material is successfully added.

Edit a Bill of Material

If you want to edit any existing bill of material in the **Bill of Materials** page, do the following,

[image-1651065349619.png](#)

1. Click  (Edit icon) in the **Edit** column for the respective bill of material. See Fig 7.2.

The page shows the details of added bill of material.

[image-1651065372737.png](#)

Image not found or type unknown

2. Click on any box where you want to edit the details, and then edit the details in the respective box.
3. Click **Save**.

Clone a Bill of Material

The **Clone** option in the **Clone** column of the **Bill of Materials** page used to add a bill of material as a copy of the previously added bill of material, See Fig 7.2.

[image-1651065434502.png](#)

1. Click  (Clone icon) in the **Clone** column of the **Bill of Materials**

A new box opens to add the bill of material.

2. Enter the details of the bill of material.

The new bill of material will be added.

Delete a Bill of Material



If you want to delete any specific bill of material from the list of bill of materials, you can use 

Image not found (Delete icon) provided in the **Delete** field of the **Bill of Materials** page.

Export Bill of Materials List


You can export a list of bill of materials added in the **Bill of Materials** page in the excel formats by 

using 

Import Multiple Bill of Materials

If you want to import multiple bill of materials together, do the following,



1. Click  on the **Bill of Materials**. See Fig 1.2.

A template will be downloaded as an excel worksheet to enter the details of bill of materials.



Image not found or type unknown

2. Enter the relevant details in the required columns on the excel worksheet.

3. Once you have added the bill of materials details in the excel worksheet, save the excel worksheet on your computer.



4. Click . See Fig 1.2.

A new box opens for importing the excel worksheet saved on your computer.



Image not found or type unknown



5. Click  to select the excel worksheet to be uploaded.

6. Select the excel worksheet you want to upload from your computer.

[image-1651065749637.png](#)

7. Click **Upload** button to export the bill of materials details that are included in the excel worksheet.

The details of the bill of materials in the worksheet will be displayed in the **Bill of Materials** page.


3 Joints

In Pressure Vessel, joints are formed by welding two or more workpieces (metal or plastic) according to a particular geometry. If you want to add a joint,

The **Joints** tab in the **Engineering** menu used to the weld joints.

1. Click **Joints** in the **Engineering**

The **Weld Joints** page opens.



#	S.No	J.Group	J.Number*	Joint Type	Location	Material 1	Thickness 1	PNo 1	GNo 1	Part No 1	Material 2	Thickness 2	PNo 2	GNo 2	Part No 2	WPS Number	Diameter	J.Length	Joint Category	NDT Group	Status	Clone	Delete	Revise
	15	LS	A3	Groove		Plate		1		105	Plate		1		106	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
<input type="checkbox"/>	16	LS	A4	Double V Groove		Plate		P1		107	Plate		P1		108	WPS/24-033/01 (Primary)		120.00	Assembly Shell	Double Groove LS	Revised			
	17	LS	A5	Groove		Plate		P1		109	Plate		P1		110	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
	18	LS	A6	Groove		Plate		P1		111	Plate		P1		112	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
	19	LS	A7	Groove		Plate		P1		113	Plate		P1		114	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
	20	LS	A8	Groove		Plate		P1		116	Plate		P1		117	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
	21	LS	A9	Groove		Plate		P1		118	Plate		P1		119	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
	22	LS	B1	Groove		Plate		P1		106	Plate		P1		107	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
	23	LS	B2	Groove		Plate		P1		108	Plate		P1		109	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
	24	LS	B3	Groove		Plate		P1		108	Plate		P1		110	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
	25	LS	B4	Groove		Plate		P1		108	Plate		P1		111	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
	26	LS	B5	Groove		Plate		P1		108	Plate		P1		109	WPS/24-033/01 (Primary)		120.00	Assembly Shell		Approved			
	27	LS	B6	Groove		Plate		P1		112	Plate		P1		113	WPS/24-033/04 (Primary)		120.00	Assembly Shell		Approved			

Figure 1.3: Weld Joints page

Add a Weld Joint

If you want to add a weld joint, do the following steps,

[image-1651066760205.png](#)

1. Click **ADD** button in the **Weld Joints**

The page shows a new box to add the details of the weld joint.

2. In the Joint Group box, select the joint group name.

3. In the Joint Number box, enter the joint number.

4. In the Joint Type box, select the joint type.

5. In the **WPS Number** box, select the WPS number from a drop-down list and click

either Primary or Alternate or Repair

as type.

The selected WPS number will be added.

6. In the NDT Group box, select the NDT Group name.

7. In the Location box, enter the location name.

8. In the Nozzle Details box, enter the nozzle details.

9. In the Joint Length (mm) box, enter the joint length.

10. In the Material 1 box, select the first material and enter their group number, thickness and part number in the respective boxes.

11. In the Material 2 box, select the second material and enter their group number, thickness and part number in the respective boxes.

12. In the **Position** box, select the position of the weld joint.
13. If the joint to be done is T joint, select the checkbox of the **Is T Joint**
14. In the **Remarks** box, enter your remarks if any.
15. Click **Save**.
17. Select the NDE Plan Tab and if required change the NDT to be performed in the Before Fit up, Back Chipping, Before PWHT, PWHT, and Other NDT fields.

Before Fitup		Back chipping		Root		Overlay		NDT		PWHT		After PWHT		After Hydro		Other NDT	
PT	<input checked="" type="checkbox"/>	PT	<input checked="" type="checkbox"/>	PT	<input type="checkbox"/>	PT	<input checked="" type="checkbox"/>	PT	<input checked="" type="checkbox"/>	PWHT	<input checked="" type="checkbox"/>	PT	<input checked="" type="checkbox"/>	PT	<input checked="" type="checkbox"/>	PMI	<input checked="" type="checkbox"/>
MT	<input checked="" type="checkbox"/>					MT	<input type="checkbox"/>	MT	<input checked="" type="checkbox"/>			MT	<input checked="" type="checkbox"/>	MT	<input checked="" type="checkbox"/>	Ferrite	<input checked="" type="checkbox"/>
						UT	<input type="checkbox"/>	UT	<input type="checkbox"/>			UT	<input type="checkbox"/>	UT	<input type="checkbox"/>	Hardness	<input checked="" type="checkbox"/>
						RT	<input checked="" type="checkbox"/>	RT	<input checked="" type="checkbox"/>			RT	<input checked="" type="checkbox"/>	RT	<input type="checkbox"/>		
						EDC	<input type="checkbox"/>	EDC	<input type="checkbox"/>			EDC	<input type="checkbox"/>	EDC	<input type="checkbox"/>		
						PAUT	<input checked="" type="checkbox"/>	PAUT	<input checked="" type="checkbox"/>			PAUT	<input type="checkbox"/>	TOFD	<input checked="" type="checkbox"/>		
						TOFD	<input type="checkbox"/>	TOFD	<input type="checkbox"/>			TOFD	<input checked="" type="checkbox"/>				
RT %		Shots		RT %		Shots		RT %		Shots		RT %		Shots			
100				0				0									
WF <input type="checkbox"/>		WC <input type="checkbox"/>		WF <input type="checkbox"/>		WC <input type="checkbox"/>		WF <input type="checkbox"/>		WC <input type="checkbox"/>		WF <input type="checkbox"/>		WC <input type="checkbox"/>			

image-1651067048222.png

Note: The NDT type displayed in all above fields can be modified based on your requirement. For example, you can add and remove the NDT type by navigating into the **NDT Requirements** tab. To know in detail, see the topic, "[NDT Requirements](#)".

Before Fit up - If you select any NDT type listed in the **Before Fit up** option for a joint, the selected NDT type should be completed before adding the Fit up inspection request for the joint. For example, if you select both **RT** and **MT**, you must do both RT and MT.

Back Chipping - If you select any NDT type listed in the **Back Chipping** option for a joint, the selected NDT type should be completed before adding the weld visual inspection request for the joint.

NDT - If you select any NDT type listed in the **NDT** option for a joint, the selected NDT type should be completed after performing the weld visual inspection for the joint.

PWHT - If you select any NDT type listed in the **PWHT** option for a joint, the selected NDT type should be completed after performing the above NDT.

Other NDT - If you select any NDT type listed in the **Other NDT** option for a joint, the selected NDT type should be completed after performing the above PWHT.

The weld joint is successfully added.

Edit a Weld Joint

If you want to edit any existing weld joint in the **Weld Joints** page, do the following,

1. Click on the joint number for the respective weld joint to edit. See Fig 1.3.

The page shows the details of added weld joint.

2. Click on any box where you want to edit the details, and then edit the details in the respective box.

3. Click **Save**.

Duplicate a Weld Joint

If you want to duplicate any existing weld joint,


[image-1651067307747.png](#)

1. Click  (Add icon) of the respective weld joint.

The selected weld joint will be added as duplicated one including the revised joint number.


Delete a Weld Joint

[image-16](#)

If you want to delete any specific weld joint from the list of added weld joints, you can use  (Delete icon) provided in the **Delete** field of the **Weld Joints** page.

View Welding Work Instruction Detail

[image-1651067382140.png](#)

If you want to view the welding work instruction detail, click  (Print icon) provided in the **Report** column.

Export Weld Joints List

You can export a list of weld joints added in the **Weld Joints** page in the excel formats by using [excelimg.png](#)

 (Excel button)

Import Weld Joints from Another Vessel

You can import the weld joints of another vessel into the current vessel by using the specific functionality given in the **Weld Joints** page.

1. Click **Import from Another Vessel** option in the **Weld Joints**

The **Import from Another Vessel** window opens.

[image-1651067481564.png](#)

Image not found or type unknown

2. If you want to import the pressure vessel joints from current project, select **Current Projects** or if you want to import the pressure vessel joints from any other project, select **All Projects**.
3. In the **Equipment** box, select an equipment from which you want to import the joints.
4. Click **OK**.

The joints of the selected equipment will be added in the **Weld Joints** page.

Revision #18

Created 27 April 2022 13:02:27

Updated 27 August 2025 05:03:14 by Jnaveen